Practical No. 6

Aim: Setup a TCP server and client on a raspberry pi using Python modules to send messages and execute shell commands from within python such as starting another application

Step 1: Install socket

```
pi@raspberrypi:~ $ sudo apt-get install socket

Reading package lists... Done

Building dependency tree

Reading state information... Done

The following NEW packages will be installed:
    socket

0 upgraded, 1 newly installed, 0 to remove and 205 not upgraded.

Need to get 15.7 kB of archives.

After this operation, 58.4 kB of additional disk space will be used.

Get:1 http://mirror.ossplanet.net/raspbian/raspbian buster/main armhf socket armhf 1.1-10 [15.7 kB]

Fetched 15.7 kB in 1s (11.4 kB/s)

Selecting previously unselected package socket.

(Reading database ... 152986 files and directories currently installed.)

Preparing to unpack .../socket_1.1-10_armhf.deb ...

Unpacking socket (1.1-10) ...
```

Step 2: connect led to breadboard and boot raspberry



Step 3: Setup TCP server and run the script

```
*tcp_server.py - I:\pract6\tcp_server.py (3.7.3)*
<u>File Edit Format Run Options Window Help</u>
import socket
import RPi.GPIO as GPIO
import time
GPIO.setmode (GPIO.BOARD)
GPIO.setup(11,GPIO.OUT)
GPIO.setwarnings(False)
UDP IP='192.168.0.80'#server ip address
UDP PORT=5007
sock = socket.socket(socket.AF INET, socket.SOCK DGRAM)
sock.bind((UDP IP,UDP PORT))
while True:
    data,addr = sock.recvfrom(1024)
    d = int(data)
    if d==1:
        GPIO.output (11, GPIO.HIGH)
    elif d==0:
        GPIO.output(11, GPIO.LOW)
    print("Receiver Message : ",data)
```

Step 4: Setup TCP client and run the script

Step 5: send input to the server

```
Shell

Python 3.7.3 (/usr/bin/python3)

>>> %cd /home/pi/Downloads

>>> %Run tcp_client.py

Enter num :1
Enter num :0
```

Step 6: view output

